

# Chapter 11 Bird's-eye-view


Lin ZHANG
School of Computer Science and Technology
Tongji University



- Our task is to measure the geometric properties of objects on a plane (e.g., conveyor belt)
- Such a problem can be solved if we have its bird'seye-view image; bird's-eye-view is easy for object detection and measurement



- Three coordinate systems are required
  - Bird's-eye-view image coordinate system
  - World coordinate system
  - Undistorted image coordinate system
  - Original fisheye image





Basic idea for bird's-eye-view generation

Suppose that the transformation matrix from bird's-eye-view to WCS is  $P_{B\to W}$ , the transformation matrix from WCS to the undistorted image is  $P_{W\to I}$ , and the camera intrinsics are known

Then, given a position  $(x_B, y_B, 1)^T$  on bird's-eye-view, we can get its corresponding position in the original fisheye image as

$$\mathbf{x}_{F} = K\mathcal{D}\left(K^{-1}P_{W\to I}P_{B\to W}\begin{pmatrix} x_{B} \\ y_{B} \\ 1 \end{pmatrix}\right)$$

Then, the intensity of the pixel  $(x_B, y_B, 1)^T$  can be determined using some interpolation technique based on the neighborhood around  $\mathbf{x}_F$  on the fisheye image




Basic idea for bird's-eye-view generation

Suppose that the transformation matrix from bird's-eye-view to WCS is  $P_{B \to W}$ , the transformation matrix from WCS to the undistorted image is  $P_{W \to I}$ , and the camera intrinsics are known

The key problem is how to obtain  $P_{B \to W}$  and  $P_{W \to I}$ ?



#### • Determine $P_{B \to W}$



Note: It is valid only when you think the origin of the world CS is at the center of the bird's-eye-view image



#### • Determine $P_{B \to W}$

For a point  $(x_B, y_B, 1)^T$  on bird's-eye-view, the corresponding point on the world coordinate system is,

$$\begin{pmatrix} x_{W} \\ y_{W} \\ 1 \end{pmatrix} = \begin{bmatrix} \frac{H}{M} & 0 & -\frac{HN}{2M} \\ 0 & -\frac{H}{M} & \frac{H}{2} \\ 0 & 0 & 1 \end{bmatrix} \begin{pmatrix} x_{B} \\ y_{B} \\ 1 \end{pmatrix} \equiv P_{B \to W} \begin{pmatrix} x_{B} \\ y_{B} \\ 1 \end{pmatrix}$$

Please verify!!



#### • Determine $P_{W \to I}$

The physical plane (in WCS) and the undistorted image plane can be linked via a homography matrix  $P_{W \to I}$ 

$$\mathbf{x}_I = P_{W \to I} \mathbf{x}_W$$


If we know a set of correspondence pairs  $\left\{\mathbf{x}_{Ii},\mathbf{x}_{Wi}\right\}_{i=1}^{N}$ ,

 $P_{W o I}$  can be estimated using the least-square method



### • Determine $P_{W \to I}$

A set of point correspondence pairs; for each pair, we know its coordinate on the undistorted image plane and its coordinate in the WCS



SCST, Tongji Univ.



When  $P_{B \to W}$  and  $P_{W \to I}$  are known, the bird's-eye-view can be generated via,


$$\mathbf{x}_{F} = K\mathcal{D}\left(K^{-1}P_{W\to I}P_{B\to W}\begin{pmatrix} x_{B} \\ y_{B} \\ 1 \end{pmatrix}\right)$$



# Another example



Original fish-eye image




Undistorted image



# Another example




Original fish-eye image



Bird's-eye-view





With multiple bird's-eye-view from multiple cameras, a surround-view can be synthesized



